Implement virtual distillation, an error mitigation technique, in Qiskit

- **1. Error mitigation** is vital to enhance the performance of NISQ devices.
- 2. We wish to mitigate **incoherent** noise with virtual distillation.
- 3. We use a variant, called **dual state verification**, which requires less connectivity.

Virtual Distillation:

Uses multiples copies to supress the nondominating components exponentially fast.



- requires connectivity between every copies.
- The diagonalising gate can be challenging to implement in general.

Dual State Verification (Echo verification)

Mingxia Huo and Ying Li Phys. Rev. A 105, 022427 (2022)

Thomas E. O'Brien et al., PRX Quantum 2, 020317 (2021)

- 1. We need to convert the observable via $O = BZ_1B^{\dagger}$.
- 2. The expectation value is measured via a non-destructive measurement on an ancilla.
- 3. In the noise-less regime, the ancilla sould be pure.
- 4. We perform full tomogrphy to purify the ancilla qubit.



Improving Virtual Distillation? Turn coherent errors to incoherent ones!

Dynamical Decoupling

Decrease decoherence by taking advantage of **rapid, time-dependent control modulation** when the qubits are idling.

Pauli Twirling

Turn a noisy operator into a Pauli channel, via gate conjugation.

$$\mathcal{T}_W(\overline{M}) = rac{1}{|W|} \sum_{w \in W} \overline{wMw^\dagger} \,.$$







Fuchs, et al., Eur. Phys. J. Plus 135, 353 (2020)

Which pulses sequences should we use?

(XY8)

IBM Quantum / © 2021 IBM Corporation

Software demonstration

Inputs:

- construct_circuit(params): prepare your circuits
- measured_operator: pauli_string to be measured
- psi: initial state

https://github.com/orielkiss/qiskitresearch/tree/DSV_tutorial/qiskit_research/DSV

Outputs:

- Expectation value at each Trotter step for the raw, DSV and DSV purified circuits.
- Purity of the ancilla qubit.

Experiment (IBMQ_mumbai)

$$H = J \sum_{j=1}^{9} X_j X_{j+1} + Y_j Y_{j+1} + Z_j Z_{j+1},$$

- VD alone is not sufficient (needs purification).
- Twirling and DD improves the purity.
- Twirling and DD have little effect on the raw data.

O = ZZIIIIII



Some more

O = ZIIIIIII

- VD alone is not sufficient (needs purification).
- XY8 DD helps.
- Twirling improves the purity.
- XY8 DD + Twirling + purified VD is the best.

